

## **Instructions on Firmware V1.03**

### **Switching interfaces:**

In power-on state:

1. Choose VW mode;
2. Keep holding “+” and fire buttons till the current interface flashes;
3. When it’s flashing, press “+”or “-” button to switch among different interfaces;
4. Press fire button once to confirm the interface you chose.

**Note:** the interfaces can only be changed and selected under VW mode in power-on state. And when one interface is selected under VW mode, the interface of TC (Ni, Ti, SS, M1, M2, M3) modes will change accordingly and automatically.

### **Preheat function:**

In power-off state:

1. Keep holding “+” and fire buttons till the M1 mode appears;
2. Press the fire button 3 times to “Power”, and press “+”or “-” button to adjust the wattage of preheat;
3. Press the fire button again to “Time”, and press “+”or “-” button to adjust the second of preheat or to turn off the preheat function.